

Technical drawing of the ECHOSPEAKER 1000 showing front and side views with dimensions.

Front View Dimensions:

- Top width: 17 3/4"
- Left height: 30"
- Top mounting bracket height: 11"
- Speaker body height: 9"
- Mounting bracket width: 1 1/2"
- Bottom mounting bracket width: 3/4"

Side View Dimensions:

- Total height: 30"
- Speaker body height: 12"
- Base height: 6"
- Base width: 145
- Base diameter: Ø5 3/8"
- Base mounting bracket width: Ø5 3/4"
- Speaker body diameter: 5 1/2"

A power cable with a standard IEC connector is shown connected to the bottom of the speaker.